




GLOYCON®

PERMANENT MAKEUP CONTROL PANEL

USER MANUAL

FRONT PANEL DESCRIPTION



HOW TO USE

1. Unpack the device from a package, check if all items are undamaged
2. Connect power adapter into proper socket in the device
3. Insert power adapter to a power socket (100-240 V)
4. Press and hold the on/off button for 3 seconds
5. LED display will turn on
6. Use voltage up/down buttons to set up voltage or use preset program
7. Insert cable to tattoo machine connection
8. At this point you can use this device, it's not necessary to use a footswitch - you can use built-in manual switch button

PROBLEM RESOLUTIONS

IF YOUR PERMANENT MAKEUP MACHINE IS NOT WORKING:

- check if the power button is on
- check if power adapter is properly connected
- check if power adapter is properly insert into the socket
- check if manual footswitch is on
- adjust voltage into proper value
- try to use other permanent makeup machine
- check your connection cables - to permanent makeup machine and footswitch

TECHNICAL DATA

INPUT VOLTAGE• 100-240 V; 50/60 Hz
OUTPUT VOLTAGE• 12 V; 2.0 A
SPEED• 50-250 NPS
MEMORY• 5 programs

SAFETY MEASURES

- read user manual carefully before use and follow it
- be careful while switching power adapter into 230V socket
- before cleaning always remember to disconnect from power
- never use water to clean the product
- clean with dry cloth only
- use it only in dry environment
- keep away from heat and children
- do not open casing - any attempt of open will void the warranty
- the manufacturer declines responsibility for any product misuses
- **to reduce risk of injury or product damage keep in mind recommendations from this user manual**

GLOYCON®




GLOYCON®

PERMANENT MAKEUP CONTROL PANEL

USER MANUAL

FRONT PANEL DESCRIPTION



HOW TO USE

1. Unpack the device from a package, check if all items are undamaged
2. Connect power adapter into proper socket in the device
3. Insert power adapter to a power socket (100-240 V)
4. Press and hold the on/off button for 3 seconds
5. LED display will turn on
6. Use voltage up/down buttons to set up voltage or use preset program
7. Insert cable to tattoo machine connection
8. At this point you can use this device, it's not necessary to use a footswitch - you can use built-in manual switch button

PROBLEM RESOLUTIONS

IF YOUR PERMANENT MAKEUP MACHINE IS NOT WORKING:

- check if the power button is on
- check if power adapter is properly connected
- check if power adapter is properly insert into the socket
- check if manual footswitch is on
- adjust voltage into proper value
- try to use other permanent makeup machine
- check your connection cables - to permanent makeup machine and footswitch

TECHNICAL DATA

INPUT VOLTAGE• 100-240 V; 50/60 Hz
OUTPUT VOLTAGE• 12 V; 2.0 A
SPEED• 50-250 NPS
MEMORY• 5 programs

SAFETY MEASURES

- read user manual carefully before use and follow it
- be careful while switching power adapter into 230V socket
- before cleaning always remember to disconnect from power
- never use water to clean the product
- clean with dry cloth only
- use it only in dry environment
- keep away from heat and children
- do not open casing - any attempt of open will void the warranty
- the manufacturer declines responsibility for any product misuses
- **to reduce risk of injury or product damage keep in mind recommendations from this user manual**

GLOYCON®